




PREVENT DAMAGE TO ANCHOR LINES

YOUR LIFE DEPENDS ON IT

HIERARCHY


01. IDENTIFY THE HAZARD



IDENTIFY ALL HAZARDS IN THE ANCHOR LINE PATH. EXAMPLES OF HAZARDS:

SHARP	HOT	TOOLS	ENTANGLEMENT
ABRASIVE	CORROSSIVE	WIND	ENTRAPMENT

02. REMOVE THE HAZARD




EXAMPLES:

- REMOVE SHARP EDGE
- REMOVE HEAT SOURCE
- REMOVE SOURCE OF ENTANGLEMENT


03. AVOID THE HAZARD

3a




EXAMPLES: ALTERNATIVE ANCHOR Y HANG

3b



BARRIER DEVIATION RE-ANCHOR

04. PROTECT AGAINST THE HAZARD




- FOR EDGES, USE AN APPROPRIATE **EDGE PROTECTOR**
- FOR OTHER **SURFACE HAZARDS**, USE AN APPROPRIATE **ANCHOR LINE PROTECTOR**
- EACH ANCHOR LINE SHOULD BE INDEPENDENTLY PROTECTED

= PROTECT!

05. VERIFY

- CHECK THE LEVEL OF PROTECTION IS APPROPRIATE AND ROBUST
- IF NOT, DO NOT PROCEED
- FOR DETAILED INFORMATION SEE: ICOP 2.7.10, 2.11.3 AND ANNEX P



“IT IS ESSENTIAL THAT PRECAUTIONS ARE TAKEN TO PREVENT DAMAGE TO ANCHOR LINES”

NOTE: ONLY ONE ANCHOR LINE AND ONE ANCHOR SHOWN FOR CLARITY

KEY: 3a, 3b. SEE ANNEX P, TABLE P.1

COPYRIGHT©2016 IRATA INTERNATIONAL

FM-120ENG V009 08/09/2025

ICOP 2.11.3.2.1